



# Instructions

<b>Storage</b>	<b>Sit stand desk</b>
<b>Product description:</b> 2369ECO & 2370ECO Pull out cabinet and 2302ECO bookcase W800 x D350 x H1102 for storage use	<b>Product description</b> 03504ECO+0355ECO+6165ECO Electrical height adjustable sit stand desk
<b>Capacity:</b> Load = Max weight per shelf is 150 kg per m2 evenly placed on the respective shelf	<b>Capacity:</b> Load = Max weight 100 kg
<b>Assembly instructions:</b> The pull out cabinets (2369ECO & 2370ECO) and bookcase (2302) are delivered assembled.	<b>Assembly instructions:</b> Desk to be assembled by yourself. See assembly instructions on <a href="https://youtu.be/EyXEhuzOufk">https://youtu.be/EyXEhuzOufk</a>
<b>Recycling of the product:</b> The cabinets have been glued together and thus cannot be disassembled. Metal and wooden parts can be disposed and recycled by an approved environment and raw materials organization.	<b>Recycling of the product</b> Desks can be disassembled as seen on the video. Metal and wooden parts can be disposed and recycled by an approved environment and raw materials organization.
<b>Compliance with European norms and standards</b> Our EU Ecolabel products meets the following standards: <ul style="list-style-type: none"> <li>- EN 14073-2 – Office furniture – Part 2: Safety requirements</li> <li>- EN 14073-3:2004 Office furniture. Storage furniture. Test methods for the determination of stability and strength of the structure</li> <li>- EN 14074:2004 Office furniture – test methods for determinations of strength and durability of moving parts.</li> </ul>	<b>Compliance with European norms and standards</b> Our EU Ecolabel product meets the following standards: <ul style="list-style-type: none"> <li>- 527 - 1 Office Furniture – Work tables and desks – Part 1: Dimensions.</li> <li>- 527 – 2 Office Furniture – Work tables – Part 2: Safety, strength and durability requirements.</li> </ul>
<b>Edgeband:</b> 1.5mm ABS plastic	

## Use of product

Use: For indoor use  
Temperature: Indoor temperature ranges recommended

## Cleaning instructions

### DPL

DPL is cleaned daily by using a damp cloth and a mild cleaning agent. Do not use "soapbased" detergents or "spray-and-shine" products. A few drops of isopropylalcohol on a clean cloth can make ink stains and bacteria disappear. Isopropylalcohol can only be used on DPL and not on lacquered surfaces like edges. After cleaning the surface must be washed thoroughly with clean water and polished with a dry, soft cloth



## **Linoleum**

### **Daily cleaning**

- Clean the desk top with a moist cloth (water + pH neutral detergent)
- Remove spots immediately.

### **To clean periodically:**

- Apply a solution of 1dl pH neutral detergent (Forbo Cleaner) to 10 liters of water.
- Let the solution work for 10 minutes.
- Gently scrub the surface with a soft cloth / sponge.
- Remove the dirty water.
- Rinse with clean water and allow the surface to dry.
- Apply a thin coat of 1: 1 clean Forbo Monel maintenance film.
- Thoroughly polish with a soft, lint-free and clean cloth.

## **Laminate**

Laminate is cleaned daily by using a damp cloth and a mild cleaning agent.

Do not use "soapbased" detergents or "spray-and-shine" products.

A few drops of isopropylalcohol on a clean cloth can make ink stains and bacteria disappear.

Isopropylalcohol can only be used on laminate and not on lacquered surfaces like edges.

After cleaning the surface must be washed thoroughly with clean water and polished with a dry, soft cloth

## **Veneer**

Veneer is cleaned daily by using a damp cloth and a mild cleaning agent.

Do not use "soapbased" detergents or "spray-and-shine" products.

A few drops of isopropylalcohol on a clean cloth can make ink stains and bacteria disappear.

Isopropylalcohol can only be used on veneer and not on lacquered surfaces like edges.

After cleaning the surface must be washed thoroughly with clean water and polished with a dry, soft cloth

## **Spare parts**

Spare parts for the product will be available for a period of 5 years from the date of purchase . The parts shall be available without charge during the guarantee period if the goods are found to be faulty during normal use or at a proportionate cost if the goods were damaged by misuse.

## **Warranty and guarantees**

Dencon A/S offers 5 years of warranty and 5 years of claim right if it comes to defects on manufactured products and material.

The warranty covers damage occurred because of deficient craftsmanship performance under normal use. The warranty will lapse if the product shows signs of mishandling abuse or other physical damage.

## **Contact information**

Dencon A/S, Skyttevej 21, DK-7800 Skive, tel. +45 97 52 17 22, www.dencon.dk